i-stop OFF SWITCH [SKYACTIV-G 2.0, SKYACTIV-G 2.5]


id0140g2008000

Purpose/Function

• i-stop control is inhibited by turning on the i-stop OFF switch.

Construction


· Installed to the switch panel.



ac5wzn00002415

Operation

 The i-stop control is inhibited when the i-stop OFF switch on-signal from the instrument cluster is received.



Fail-safe

• Function not equipped.