SOLAR RADIATION SENSOR [FULL-AUTO AIR CONDITIONER]

id0740a1321100

Purpose


• The solar radiation sensor detects the sunlight intensity emitted to the cabin.

Function

• The solar radiation sensor converts the detected solar radiation amount to an electric signal.

Construction


- A photodiode (light receiving diode) has been adopted for the solar radiation sensor.
- The solar radiation sensor is installed to the passenger's side in the dashboard.



ac5wzn00000726

Operation

- The photodiode (light receiving diode) generates electrical current when light shines on the connecting area of the semiconductor. The generated electrical current increases if the sunlight intensity increases, and conversely decreases if the sunlight intensity decreases.
- The climate control unit determines the sunlight intensity according to the amount of electrical current sent from the solar radiation sensor.



ac5wzn00000727

Fail-safe

· Function not equipped.