CLUTCH STROKE SENSOR REMOVAL/INSTALLATION [D66M-R, D66MX-R]

id0510mf156900

Note

- The clutch stroke sensor is equipped only on vehicles with i-stop.
 The clutch stroke sensor is built into the clutch master cylinder.
- 1. Replace the clutch master cylinder. (See CLUTCH MASTER CYLINDER REMOVAL/INSTALLATION [D66M-R, D66MX-R].)