BEFORE SERVICE PRECAUTION [SKYACTIV-D 2.2]

id0114z7802000

Warning

- Always keep sparks and flames away from fuel. Fuel can be easily ignited which could cause serious
 injury or death, and damage to equipment
- Fuel line spills and leakage from the pressurized fuel system are dangerous. Fuel can ignite and cause serious injury or death, and damage to property and facilities. Fuel can also irritate the skin and eyes. To prevent this, always execute the following line safety procedure.
- A person charged with static electricity could cause a fire or explosion, resulting in death or serious injury. Before servicing the fuel system, make sure to discharge static electricity by touching a vehicle.

Note

• When the engine is stopped, fuel in the fuel system is pressurized.

Fuel line safety procedure

- 1. To prevent fuel spatter and leakage of the fuel system, perform the following procedure:
 - (1) Remove the fuel-filler cap to release the pressure inside the fuel tank.
 - (2) Cover the fuel hose with a rag when disconnecting it.
 - (3) Plug the hose after disconnection.