EXHAUST SYSTEM INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0115z9800100

- Start the engine and inspect each exhaust system component for exhaust gas leakage.
 If there is leakage, repair or replace the appropriate component. (See EXHAUST SYSTEM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)