COOLING FAN RELAY [SKYACTIV-D 2.2]


id0112s6158700

Purpose, Function

• The cooling fan relay operates by receiving the signal from the PCM to supply power to the cooling fan motor.

Construction


· The cooling fan relay is installed on the relay box.



ac5wzn00001833

Operation

The contact point is on when the voltage is supplied to the coil based on the signal from the main relay, and the battery voltage is supplied to the fan control module.



Fail-safe

• Function not equipped.