FRONT SASH MOLDING REMOVAL


id091600805000

Warning


- Using a utility knife with bare hands can cause injury. Always wear gloves when using a utility knife.
- 1. Using a utility knife, carefully remove the double-sided adhesive tape in the locations shown below.

Caution

• When removing the double-sided adhesive tape, be careful not to damage clip A.



2. Insert a tape-wrapped flathead screwdriver shown in the figure and remove the protector in the direction of arrow (1).



3. Insert a tape-wrapped flathead screwdriver shown in the figure and remove clip A in the direction of arrow (2).

