CYLINDER HEAD GASKET [SKYACTIV-D 2.2]


id0110s5000300

Purpose, Function

 The cylinder head gasket covers the area between the cylinder heads and cylinder block to prevent leakage of air-fuel mixture, combustion gas, engine oil, and engine coolant.

Construction

• A four-layer type metal gasket has been adopted for the cylinder head gasket.



ac5wzn00001999