
GLOBAL POSITIONING SYSTEM (GPS) ANTENNA REMOVAL/INSTALLATION

id002000801500

- 1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
- 2. Remove the center speaker grille. (see SPEAKER GRILLE REMOVAL/INSTALLATION.)
- 3. Disconnect the connector.
- 4. Remove the screw.
- 5. Remove the GPS antenna.
- 6. Install in the reverse order of removal.



ac5wzw00000716