CLUTCH PEDAL POSITION (CPP) SWITCH [SKYACTIV-G 2.0, SKYACTIV-G 2.5]


id0140g2008200

Purpose/Function

Detects the connection status of the clutch.

Construction


- Installed on the clutch pedal.
- · An ON/OFF type switch has been adopted.




ac5wzn00002420

Operation

• Sends the CPP switch on/off signal to the PCM.



The contact point is on and voltage is output when the clutch pedal is engaged, and off when the clutch pedal is not engaged.



Fail-safeFunction not equipped.