CD PLAYER SCRATCHES ON THE CD [CD PLAYER]

id0903k3016900

Possible DTC	CD player scratches on the CD		
	Using the M-MDS	B1188:64	
Possible DTC	Without using M-MDS (On- board diagnostic test mode)	10:Er07	
Possible cause	 Deformed disc is used (e.g., out of specification (thickness), bent disc) Multiple CDs are inserted into the CD player at the same time Audio unit malfunction 		

Diagnostic procedure

Diagnostic procedure					
STEP	INSPECTION		ACTION		
1	Were the multiple CDs inserted into the CD	Yes	Explain to the customer to insert a CD one by one.		
	player at the same time?	No	Go to the next step.		
2	Visually inspect the CD. Is the CD a deformed disc (e.g., out of	Yes	Audio system is normal. Explain to the customer that the CD is malfunctioning.		
	specification (thickness), bent disc)?	No	Replace the audio unit. (See AUDIO UNIT REMOVAL/INSTALLATION.)		