## **CRUISE MAIN INDICATOR LIGHT (AMBER) [SKYACTIV-D 2.2]**


id0120e5903600

# **Purpose/Function**

• Illuminates while the cruise control system is in standby mode to inform the driver that the cruise control system is on standby.

### Construction

· Built into the instrument cluster.



ac5wzn00002343

#### Operation

- Illuminates while the cruise control system is on standby.
- The PCM sends a cruise main indicator light (amber) illumination request to the instrument cluster via CAN communication.

### Fail-safe

· Function not equipped.