DISPLAY SCREEN DOES NOT CHANGE TO THE NIGHT MODE [CAR-NAVIGATION SYSTEM]

id0903e8100400

Possible DTC	Does not switch to the night screen even though the light switch is in the TNS position.	
	Car-navigation unit malfunction	
POSSIBLE CAUSE	TNS signal malfunction	
	Open, short circuit in car-navigation unit terminal 1E	

Diagnostic Procedure

Step	Inspection		Action
1	VERIFY TNS SIGNAL	Yes	Go to the next step.
	Launch the audio unit diagnostic assist function.	No	Go to Step 3.
	(See DIAGNOSTIC ASSIST FUNCTION		
	[AUDIO].)		
	Select diagnostic assist code 15 vehicle NAVI signal verification		
	signal verification.		
	Does the TNS display OFF? NORTH TNS CLONAL	V	On to the count of a
2	INSPECT TNS SIGNAL	Yes	Go to the next step.
	Measure the terminal voltage at audio unit	No	Inspect the applicable (TNS signal system) vehicle
	connector (24-pin) terminal 1E.		panel and repair or replace.
	Is the voltage normal?		
	Specification		
	TNS ON: Approx. 12. V		
	TNS OFF: Approx. 0 V		
3	VERIFY IF SYSTEM SWITCHES TO NIGHT	Yes	System is normal.
	SCREEN	No	Replace the audio unit.
	Turn the light switch to the TNS position.		(See AUDIO UNIT REMOVAL/INSTALLATION.)
	Does the audio unit screen switch to the night		
	screen?		