SEDIMENTOR SWITCH [SKYACTIV-D 2.2]


id0114z7707900

Purpose, Function

• Detects the water level in the sedimentor. The float rises according to the level of accumulated water. If the water level exceeds the specification, the circuit for the sedimentor switch is completed.

Construction


· The sedimentor switch is installed to the fuel filter.



ac5wzn00001970

Operation

If the water level in the sedimentor exceeds a certain level, the sedimentor switch turns on, which is input to the PCM.



ac5wzn00002119