BRAKE FLUID INSPECTION

- Verify that the brake fluid level in the brake fluid reserve tank is between the MAX and MIN marks.
 - If the brake fluid level is below the MIN mark, add brake fluid.

id041100815200

