REMOTE TRANSMITTER

Purpose


• When the lock button/unlock button of the remote transmitter is pressed, ID data is sent to the keyless receiver.

Function

· When the remote transmitter sends ID data, the operation indicator light illuminates.

Construction

- · The remote transmitter is built into the operation indicator light.
- The remote transmitter secures specific electronic codes (key ID number) built into the electronic communication device (transponder).
- In case the transmitter is inoperable due to battery depletion, the doors can be locked/unlocked using the auxiliary key.



ac5wzn00001093

Operation

 When a remote transmitter button is pressed, ID data at a radio frequency of 433 MHz is sent to the keyless receiver.

Fail-safe

· Function not equipped.