FRONT DOOR LATCH AND LOCK ACTUATOR INSPECTION

id091400511200

- The following actuator and switches are integrated with the front door latch and lock actuator.
 From the actuator/switch name and operation in the following table, select the actuator or switch to be inspected, and perform the inspection following the inspection procedure described in the reference.

Actuator/Switch name	Operation	Reference
Front door lock actuator	Electrically switches the lock/unlock of the front	FRONT DOOR LOCK ACTUATOR
	doors.	INSPECTION
Front door lock-link switch	Turns on/off in conjunction with the lock/unlock	DOOR LOCK-LINK SWITCH
	so that the lock/unlock condition is detected.	INSPECTION
Front door latch switch	Turns on/off in conjunction with the latch lever	FRONT DOOR LATCH SWITCH INSPECTION
	operation so that the front door open/closed	
	condition is detected.	
Front door key cylinder switch	Turns on/off in conjunction with the lock/unlock	FRONT DOOR KEY CYLINDER SWITCH INSPECTION
	of the front door key cylinder so that the key	
	cylinder operation condition is detected.	