SYMPTOM TROUBLESHOOTING

id030300800300

• Verify the symptoms, and perform troubleshooting according to the appropriate number.

No.	Symptom	Description
1	Frequent front wheel slip	Front wheels slip frequently during acceleration on low-friction road.
2	Tight corner braking effect	Brakes seem to be applied during tight cornering while driving very slowly on paved road.
3	Abnormal noise and/or vibration from	There is abnormal noise and/or vibration from coupling unit during
	coupling unit	driving.