## PARKING SENSOR SWITCH/INDICATOR REMOVAL/INSTALLATION

id092200023700

## Note

- The parking sensor switch/indicator is integrated with the climate control unit.
  For the parking sensor switch/indicator removal/installation, refer to the climate control unit removal/installation. (See CLIMATE CONTROL UNIT REMOVAL/INSTALLATION [FULL-AUTO AIR CONDITIONER].)