## OIL FILTER [SKYACTIV-G 2.0, SKYACTIV-G 2.5]


id0111h5002200


## **Purpose, Function**

• Engine oil is filtered by passing engine oil through the oil filter element.

## Construction

- The oil filter is installed on the right side surface of the cylinder block.
  A spin-on type (full-flow type) oil filter has been adopted.





The bypass valve is equipped as a detour if the oil filter element becomes clogged.

