## ADAPTIVE FRONT LIGHTING SYSTEM (AFS) OFF SWITCH REMOVAL/INSTALLATION

id091800112400

## Note

- The AFS OFF switch is integrated with the cluster switch.
  For the cluster switch removal/installation, refer to "SWITCH PANEL REMOVAL/INSTALLATION" because the cluster switch is installed to the switch panel. (See SWITCH PANEL REMOVAL/INSTALLATION.)