Purpose


· Alerts that a door, liftgate, or the bonnet has been opened improperly.

Function

• The theft-deterrent system activates if a door, the liftgate, or the bonnet is improperly opened.

Open Circuit Alert Control Function

- If the power or ground lines are cut, the theft-deterrent siren uses the back-up power supply to activate the siren.
- If the transmission lines are cut, the theft-deterrent system uses the vehicle's battery power to activate the siren.
- If any one of the following conditions are met, the siren is stopped:
 - Receives go-to-initial signal from the rear body control module (RBCM)




Construction

• The theft-deterrent siren is installed inside the front bumper on the left side.

Operation

• The siren beeps when receiving an alert initialization signal from the rear body control module (RBCM). When a go-to-initial signal is received the siren is stopped.



ac5wzn00000926

Fail-safe

Function not equipped.