POWER WINDOW MOTOR

id091200012400

Purpose


The power window motor transmits rotation force to the power window regulator to open/close the door glass.

Function

The power window motor rotates clockwise/counterclockwise when it receives an open/close signal from the power window main switch or the power window subswitch.

Construction


- · The power window motor consists of the following parts:
 - Motor
 - Connector
 - Gear
- Two Hall effect switches are located in each power window motor connector. (With auto open/close function for all doors)
 - The Hall effect switches output pulse to the P/W CM.
- Two Hall effect switches are located in the driver's side connector. (With auto open/close function for driver's side door)
 - The Hall effect switches output pulse to the P/W CM.



ac5wzn00000403

Operation

- The Hall effect switch utilizes magnets set on a rotating axis to detect the motor rotation, and outputs a synchronized pulse to the P/W CM.
- The Hall effect switch 1 outputs one pulse cycle for each rotation of the power window motor axle, and the P/W CM detects motor rotation speed.
- Hall effect switch 2 outputs pulse according to the motor rotation in the same manner as Hall effect switch 1. The
 high and low pulse points of Hall effect switches 1 and 2 are different during opening and closing because the
 phase difference shifts by 90°, allowing the power window main switch to detect the rotational direction of the
 power window motor.



Fail-safe

• Function not equipped.