
MANUAL TRANSAXLE SHIFT MECHANISM LOCATION INDEX [C66M-R, C66MX-R]

id0516c8160600



1 Shift lever
(See MANUAL TRANSAXLE SHIFT MECHANISM REMOVAL/INSTALLATION [C66M-R, C66MX-R].)

2 Control cable (See MANUAL TRANSAXLE SHIFT MECHANISM REMOVAL/INSTALLATION [C66M-R, C66MX-R].)