ACCESSORY SOCKET

# **Purpose**


• By inserting the plug of an electrical device, 12 V (maximum 120 W) of power is supplied enabling use of the electrical device in the vehicle.

### **Function**

• When the ignition is switched to ACC or ON (engine off or on), 12 V (maximum 120 W) of power is supplied.

#### Construction

- · A cap is installed to prevent penetration of foreign matter in the socket such as dust.
- A front accessory socket is installed to the front console.
- A center accessory socket is installed inside the rear console.
- A rear accessory socket is installed to the trunk side trim (RH).



ac5wzn00000286

# Operation

1. When the ignition is switched to ACC or ON (engine on or off), power is supplied constantly.

### Fail-safe

· Function not equipped.