
DISC PAD (REAR) REPLACEMENT

id041100800300

- 1. Remove in the order indicated in the table.
- 2. Install in the reverse order of removal.
- 3. After installation, pump the brake pedal a few times and inspect the following:
 - The disc pad projection is securely installed to the piston groove
 Parking brake lever stroke
 Brake drag



1	Bolt
2	Caliper
	(See REAR BRAKE (DISC) REMOVAL/
	INSTALLATION.)

	ac5wzw0000228	36
3	Disc pad	
4	Shim	
5	Guide plate	