### i-stop OFF SWITCH [SKYACTIV-D 2.2]


id0140z7008000

# Purpose/Function

• i-stop control is inhibited by turning on the i-stop OFF switch.

#### Construction


Installed to the switch panel.



ac5wzn00002458

# Operation

 The i-stop control is inhibited when the i-stop OFF switch on-signal from the instrument cluster is received.



### Fail-safe

• Function not equipped.