DTC P252F:00 [SKYACTIV-D 2.2]

id0102s4154300

DTC P252F: 00	Engine oil level too high			
DETECTION CONDITION	 The amount of engine oil dilution exceeds 1,661 g {58.59 oz} during the diesel particulate filter regeneration control. Diagnostic support note This is a continuous monitor (other). The check engine light does not illuminate. FREEZE FRAME DATA (Mode 2)/Snapshot data is not available. DTC is stored in the PCM memory. 			
FAIL-SAFE FUNCTION	Not applicable			
POSSIBLE CAUSE	 Engine oil attenuation by frequently diesel particulate filter regeneration Engine oil data reset procedure does not perform in each engine oil replacements. PCM malfunction 			
SYSTEM WIRING DIAGRAM	Not applicable			

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/	Yes	Go to the next step.
	SNAPSHOT DATA HAS BEEN RECORDED	No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data
	 Has the FREEZE FRAME DATA (Mode 2)/ 		on the repair order, then go to the next step.
	snapshot data been recorded?		
2	VERIFY RELATED SERVICE INFORMATION	Yes	Perform repair or diagnosis according to the available
	AVAILABILITY		Service Information.
	 Verify related Service Information availability. 		 If the vehicle is not repaired, go to the next step.
	Is any related Service Information available?	No	Go to the next step.
3	INSPECT ENGINE OIL LEVEL	Yes	Replace the engine oil.
	Inspect the engine oil level.		(See ENGINE OIL REPLACEMENT [SKYACTIV-D 2.2].)
	 Is the engine oil amount above X line on the 		Perform the "ENGINE OIL DATA RESET", then go to Step
	dipstick?		5.
			(See ENGINE OIL DATA RESET [SKYACTIV-D 2.2].)
		No	Go to the next step.
4	VERIFY RELATED PENDING CODE AND/OR	Yes	Replace the engine oil.
	DTC		(See ENGINE OIL REPLACEMENT [SKYACTIV-D 2.2].)
	 Switch the ignition off, then ON (engine off). 		Perform the "ENGINE OIL DATA RESET", then go to the
	Perform the Pending Trouble Code Access		next step.
	Procedure and DTC Reading Procedure.		(See ENGINE OIL DATA RESET [SKYACTIV-D 2.2].)
	(See ON-BOARD DIAGNOSTIC TEST	No	Go to the next step.
	[SKYACTIV-D 2.2].)		
	 Is the PENDING CODE/DTC P253F:00 also 		
	present?		

STEP	INSPECTION		ACTION
5	VERIFY DTC TROUBLESHOOTING	Yes	Replace the PCM, then go to the next step.
	COMPLETED		(See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
	Clear the DTC from the PCM memory using the	No	Go to the next step.
	M-MDS.		
	(See AFTER REPAIR PROCEDURE		
	[SKYACTIV-D 2.2].)		
	Start the engine and warm it up completely.		
	Caution		
	While performing this step, always operate		
	the vehicle in a safe and lawful manner. • When the M-MDS is used to observe monitor system status while driving, be sure to have another technician with you, or record the data in the M-MDS using the PID/DATA MONITOR AND RECORD		
	capturing function and inspect later.		
	Drive the vehicle under the FREEZE FRAME		
	DATA (Mode 2)/snapshot data condition.		
	Perform the DTC Reading Procedure.		
	(See ON-BOARD DIAGNOSTIC TEST		
	[SKYACTIV-D 2.2].)		
6	Is the same DTC present? VERIFY AFTER REPAIR PROCEDURE	Yes	Go to the applicable DTC inspection.
0	Perform the "AFTER REPAIR PROCEDURE".	168	(See DTC TABLE [SKYACTIV-D 2.2].)
	(See AFTER REPAIR PROCEDURE	No	DTC troubleshooting completed.
	[SKYACTIV-D 2.2].)	140	DIO Housiconouting completed.
	• Are any DTCs present?		