BLIND SPOT MONITORING (BSM) OFF SWITCH

id092200027600

Purpose


The blind spot monitoring (BSM) system can be turned on or off optionally by the driver.

Function

The switch operation signal is sent to the instrument cluster.

Construction


- · The BSM OFF switch is built into the cluster switch.
- The resistance is built into each switch.



ac5wzn00001451

Operation

- 1. When the BSM OFF switch operates, the switch operation signal is sent to the instrument cluster.
- 2. The instrument cluster sends a BSM OFF switch operation signal to the BSM control module based on the received voltage value (switch operation signal).
- 3. The BSM control module switches the BSM system on/off when it receives the BSM OFF switch operation signal from the instrument cluster.



ac5wzn00000890

Fail-safe

· Function not equipped.