ROLLOVER VALVE [SKYACTIV-G 2.0, SKYACTIV-G 2.5]


id0116zb122900

Purpose, Function


• Prevents fuel from flowing into the evaporative gas passage during sudden cornering or vehicle rollover.

Construction

• The rollover valve is built into the fuel tank.




The rollover valve consists of a float, O-ring and spring.



Operation

The rollover valve utilizes a combination of float weight, spring force, and buoyancy. When the float is immersed in the fuel, the float (valve) closes to block the sealing surface of the passage.



am3uun00002166