DTC U3000:49 [ADAPTIVE FRONT LIGHTING SYSTEM (AFS)]

id09021n935100

System	AFS control module internal malfunction		
malfunction	RAM/ROM malfunction		
location	AFS function malfunction		
location	CAN hardware malfunction		
	RAM/ROM malfunction		
	The AFS control module detected a malfunction in the internal RAM/ROM.		
Detection	AFS function malfunction		
condition	 The AFS control module detected AFS function malfunction three times. 		
	CAN hardware malfunction		
	 The AFS control module detected CAN hardware malfunction three times. 		
	RAM/ROM malfunction		
	— The swivel actuator is moved to the center.		
	 The headlight leveling actuator is stopped at the position when the malfunction is determined. 		
Fail-safe	AFS function malfunction		
Fall-Sale	- -		
	CAN hardware malfunction		
	— The swivel actuator is moved to the center.		
	The headlight leveling actuator is stopped at the position when the malfunction is determined.		
Possible cause	AFS control module internal malfunction		
System wiring			
diagram	_		

Diagnostic Procedure

Step	Inspection		Action
1	PERFORM DTC INSPECTION AND VERIFY IF	Yes	Replace the AFS control module, then go to the next step.
	MALFUNCTIONING PART IS AFS CONTROL		(See ADAPTIVE FRONT LIGHTING SYSTEM (AFS)
	MODULE		CONTROL MODULE REMOVAL/INSTALLATION.)
	Clear the AFS control module DTCs using the M-MDS. (See CLEARING DTC [ADAPTIVE FRONT LIGHTING SYSTEM (AFS)].) Perform the DTC inspection for the AFS control module using the M-MDS. (See DTC INSPECTION [ADAPTIVE FRONT LIGHTING SYSTEM (AFS)].)	No	Go to the next step.
2	• Is DTC U3000:49 displayed? VERIFY IF OTHER DTCs DISPLAYED	Yes	Repair the malfunctioning part according to the applicable
2	• Are any other DTCs displayed?	res	DTC troubleshooting.
			(See DTC TABLE [ADAPTIVE FRONT LIGHTING
			SYSTEM (AFS)].)
		No	DTC troubleshooting completed.