CLUTCH PEDAL POSITION (CPP) SWITCH [SKYACTIV-D 2.2]


id0140z7008200

Purpose/Function

Detects the connection status of the clutch.

Construction


- Installed on the clutch pedal.
- An ON/OFF type switch has been adopted.




ac5wzn00002460

Operation

• Sends the CPP switch on/off signal to the PCM.



The contact point is on and voltage is output when the clutch pedal is engaged, and off when the clutch pedal is not engaged.



ac5wzn00002462

Fail-safeFunction not equipped.