OIL STRAINER [FW6A-EL, FW6AX-EL]


id0517h2355300

Purpose/Function

• The oil strainer filters particulate matter in the ATF by passing it through the built-in filter.

Construction

• The oil strainer is a built-in, non-woven fabric filter installed to the position shown in the following figure.



am3uun00002256