CARGO COMPARTMENT LIGHT

id091800012600


Purpose

• The cargo compartment light illuminates the cargo room interior when the liftgate is opened.

· When the liftgate is opened, illuminates by the cargo room light switch turning on.

Construction


The cargo room light is installed to the trunk side trim.



ac5wzn00000445

Operation

- 1. When the liftgate opens, the liftgate latch switch turns on and a liftgate light switch on signal is input to the rear body control module (RBCM).
- When the rear body control module (RBCM) inputs the liftgate latch switch, electric current flows to the cargo room light.
- When the cargo room light switch turns on, electric current flows to the cargo light bulb.
- When electric current flows to the cargo room light bulb, the cargo room light bulb illuminates.



ac5wzn00001365

Fail-safe

· Function not equipped.