LIFTGATE LATCH AND LOCK ACTUATOR INSPECTION

id091400517000

- The following actuator and switch are integrated with the liftgate latch and lock actuator.
 From the actuator/switch name and operation in the following table, select the actuator or switch to be inspected, and perform the inspection following the inspection procedure described in the reference.

Actuator/Switch name	Operation	Reference
Liftgate lock actuator	Electrically unlatches the liftgate based on the signal from the rear body control module (RBCM).	LIFTGATE LOCK ACTUATOR INSPECTION
Liftgate latch switch	Turns on/off in conjunction with the latch lever rotation so that the liftgate open/closed condition is detected.	LIFTGATE LATCH SWITCH INSPECTION