COOLING FAN RELAY [SKYACTIV-G 2.0, SKYACTIV-G 2.5]


id0112h6158700

Purpose, Function

• The cooling fan relay operates by receiving the signal from the PCM to supply power to the cooling fan motor.


Construction

· The cooling fan relay is installed to the relay and fuse block.



Operation

The contact point is on when the battery voltage is supplied to the coil based on the signal from the PCM, and the battery voltage is supplied to the cooling fan motor.



ac5wzn00002177

Fail-safe

· Function not equipped.