
HORN REMOVAL/INSTALLATION

id092200012600

- 1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)(See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].)(See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].
- Remove the front bumper.
 Disconnect the connector. Remove the front bumper. (See FRONT BUMPER REMOVAL/INSTALLATION.)

TYPE A



TYPE B

- 4. Remove the bolt.
- 5. Remove the horn.
- 6. Install in the reverse order of removal.

