
INTAKE MANIFOLD [SKYACTIV-D 2.2]

id0113z7003700

Purpose, Function

- Distributes intake air to each cylinder evenly.
 Optimizes the combustion efficiency and performance of the engine by distributing intake air to each cylinder.

ConstructionThe intake manifold is installed to the cylinder head.



ac5wzn00001937