
TURBINE/INPUT SHAFT SPEED SENSOR, OUTPUT SHAFT SPEED SENSOR [FW6A-EL, FW6AX-EL]

Purpose/Function

- The turbine/input shaft speed sensor detects the rotation speed of the input shaft (low clutch drum).
- The output shaft speed sensor detects the rotation speed of the output shaft (primary gear).
- The turbine/input shaft speed sensor and output shaft speed sensor signals are used for automatic shift control, manual shift control, and the on-board diagnostic system.

Construction

• The turbine/input shaft speed sensor and output shaft speed sensor are both integrated with the TCM and built-into the control valve body.



am3uun00002424

Operation

- The turbine/input shaft speed sensor changes the output signal according to the rotation speed of the low clutch
 drum.
- The output shaft speed sensor changes the output signal according to the rotation speed of the primary gear.