
PARKING BRAKE LEVER ADJUSTMENT

id041200801500

- 1. Pump the brake pedal a few times.
- 2. Remove the upper console and put it out of the way. (See REAR CONSOLE DISASSEMBLY/ASSEMBLY.)
- Turn the adjusting nut and adjust the parking brake lever.
- 4. After adjustment, pull the parking brake lever one notch and verify that the parking brake warning light illuminates.
- 5. Verify that the rear brakes do not drag.



ac5wzw00000239