
RELAY LOCATION



2 Electric AT oil pump relay

A/C relay
Headlight HI relay
SKYACTIV-G 2.0, SKYACTIV-G 2.5:
Fuel injector relay
SKYACTIV-D 2.2:
Check connector
Fuel pump relay
Halogen type:
Headlight LO relay
Discharge type:
Headlight LO relay (LH)
IG1 relay
Starter relay
Outlet relay
Horn relay
Brake light relay
ACC relay
Cooling fan relay No.1
SKYACTIV-G 2.0, SKYACTIV-G 2.5:
Electric variable valve timing relay
SKYACTIV-D 2.2:
Blow-by heater relay

16	SKYACTIV-G 2.0, SKYACTIV-G 2.5:
	Cooling fan relay No.2
	SKYACTIV-D 2.2:
	Ignition relay (ACC_STAB)
17	Blower relay
18	Headlight LO relay (RH)
19	Rear window defroster relay
20	SKYACTIV-G 2.0, SKYACTIV-G 2.5:
	Cooling fan relay No.3
	SKYACTIV-D 2.2:
	Ignition relay (IG1_STAB)
21	Front fog light relay
22	Main relay
23	Ignition relay (ACC_STAB)
24	Ignition relay (IG1_STAB)
25	Cooling fan relay No.2
26	Cooling fan relay No.1