

ac5wzw00003116

1 Antenna feeder No.1	
(Cas ANTENNA FEEDED LOCATION)	
(See ANTENNA FEEDER LOCATION.) (See ANTENNA FEEDER NO.1 REMOVAL	,
INSTALLATION.)	-
(See ANTENNA FEEDER NO.1 INSPECTION	
2 Glass antenna (with RDS (radio data syster	
(See GLASS ANTENNA INSPECTION.)	''''
3 Center roof antenna	
(See CENTER ROOF ANTENNA REMOVA	J /
INSTALLATION.)	
(See CENTER ROOF ANTENNA INSPECT	TON.)
4 Antenna feeder No.3	
(See ANTENNA FEEDER LOCATION.)	
(See ANTENNA FEEDER NO.3 REMOVAL	./
INSTALLATION.)	
(See ANTENNA FEEDER NO.3 INSPECTION	ON.)
5 Antenna feeder No.2	
(See ANTENNA FEEDER LOCATION.)	
(See ANTENNA FEEDER NO.2 REMOVAL	./
INSTALLATION.)	on.
(See ANTENNA FEEDER NO.2 INSPECTION	
6 Rear mount camera (with park assist syster (See REAR MOUNT CAMERA REMOVAL/	
INSTALLATION.)	
(See REAR MOUNT CAMERA INSPECTION	ואו
7 Car-navigation unit (with car-navigation sys	
(See CAR-NAVIGATION UNIT REMOVAL/	
INSTALLATION.)	
(See SD CARD UPDATING PROCEDURE.	.)
8 AudioPilot ®2 microphone (with Bose®)	'
(See AudioPilot®2 MICROPHONE REMOV	/AΙ /
INSTALLATION.)	,,
9 Audio unit (with audio system)	
(See AUDIO UNIT REMOVAL/INSTALLATI	ON.)
(See AUDIO UNIT PERSONALIZATION	,
FEATURES SETTING PROCEDURE.)	
10 Rear door speaker	
(See REAR DOOR SPEAKER REMOVAL/	
INSTALLATION.)	
(See REAR DOOR SPEAKER INSPECTIO	N.)
11 Front door speaker	
(See FRONT DOOR SPEAKER REMOVAL	./
INSTALLATION.)	 .
(See FRONT DOOR SPEAKER INSPECTION	UN.)

12	Steering switch (See STEERING SWITCH REMOVAL/ INSTALLATION.)
	(See STEERING SWITCH INSPECTION.)
13	Microphone (with Bluetooth system) (See MICROPHONE REMOVAL/INSTALLATION.)
14	Tweeter (6 speaker type, with Bose [®]) (See TWEETER REMOVAL/INSTALLATION.) (See TWEETER INSPECTION.)
15	Front center speaker (With Bose®) (See FRONT CENTER SPEAKER REMOVAL/ INSTALLATION.) (See FRONT CENTER SPEAKER INSPECTION.)
16	GPS antenna (with car-navigation system) (See GLOBAL POSITIONING SYSTEM (GPS) ANTENNA REMOVAL/INSTALLATION.)
17	Audio amplifier (with Bose®) (See AUDIO AMPLIFIER REMOVAL/ INSTALLATION.)
18	Bluetooth unit (with Bluetooth system) (See Bluetooth UNIT REMOVAL/INSTALLATION.)
19	Cigarette lighter (See CIGARETTE LIGHTER REMOVAL/ INSTALLATION.) (See CIGARETTE LIGHTER INSPECTION.)
20	Commander switch (with commander switch) (See COMMANDER SWITCH REMOVAL/ INSTALLATION.) (See COMMANDER SWITCH INSPECTION.)
21	Auxiliary jack/USB port (See AUXILIARY JACK/USB PORT REMOVAL/ INSTALLATION.) (See AUXILIARY JACK/USB PORT INSPECTION.)
22	Condenser (See CONDENSER REMOVAL/INSTALLATION.)
23	D-pillar speaker (with Bose [®]) (See D-PILLAR SPEAKER REMOVAL/ INSTALLATION.) (See D-PILLAR SPEAKER INSPECTION.)