STARTER INTERLOCK SWITCH [SKYACTIV-D 2.2]


id0119h8133000

Purpose, Function

• The starter interlock switch mechanism prevents vehicle surge when the engine is started, enhancing safety. The engine cannot be started unless the clutch is depressed.

Construction


 The mechanism is provided with a starter interlock switch on the circuit under the START STOP UNIT and the PCM



ac5wzn00001556

Operation

• Depressing the clutch pedal presses the starter interlock switch rod. At this time, the starter interlock switch is on, and the power circuit to the starter closes. Accordingly, the starter operates only when the clutch is depressed and the engine can be started.



am3uun00002404

Fail-safe

• Function not equipped.