NEUTRAL SWITCH [SKYACTIV-D 2.2]


id0140z7008100

Purpose/Function

Detects the neutral position of the shift lever.


Construction

- · Installed to the manual transaxle.
- An ON/OFF type switch has been adopted.




Operation


• Sends the neutral switch on/off signal to the PCM.



The contact point is on when in neutral to output voltage and off when not in neutral.



ac5wzn00000030



Fail-safe
• Function not equipped.