
REAR DIFFERENTIAL LOCATION INDEX

id031400800300



1	Differential oil
	(See DIFFERENTIAL OIL INSPECTION.)
	(See DIFFERENTIAL OIL REPLACEMENT.)
2	Oil seal (side gear)
	(See OIL SEAL (SIDE GEAR) REPLACEMENT.)
3	Oil seal (coupling component)
	(See OIL SEAL (COUPLING COMPONENT)
	REPLACEMENT.)

4 Rear differential
(See REAR DIFFERENTIAL REMOVAL/
INSTALLATION.)
(See REAR DIFFERENTIAL DISASSEMBLY.)
(See REAR DIFFERENTIAL ASSEMBLY.)