TROUBLESHOOTING INDEX [PARKING SENSOR]

id0903z4668500

| N | Troubleshooting item | Description |
|---|--|---|
| 0 | | |
| 1 | SYSTEM DOES NOT OPERATE [PARKING SENSOR] | Buzzer does not sound and the parking sensor indicator does not illuminate even if the parking sensor switch is turned on. |
| 2 | MALFUNCTION DETECTION SOUND ACTIVATED [PARKING SENSOR] | Buzzer sounds after turning the parking sensor switch/ indicator on. |
| 3 | NO DETECTION SOUND/LOW VOLUME [PARKING SENSOR] | Buzzer does not sound (parking sensor indicator illumination is normal) after turning the parking sensor switch/indicator on. The volume of the detection sound from the buzzer decreases. |
| 4 | INDICATOR LIGHT DOES NOT ILLUMINATE [PARKING SENSOR] | The parking sensor indicator does not illuminate (buzzer is normal) when the parking sensor switch/indicator is turned on. The parking sensor indicator does not illuminate (buzzer is normal) even though the detection condition is met. |