TRUNK FLOOR PANEL REMOVAL [PANEL REPLACEMENT]

id098008829500

Symbol Mark

SYMBOL MARK	MEANING
•	SPOT WELDING


ac5wzb00000090

Removal Procedure

1. Drill the 96 locations shown in the figure.

Caution

When drilling the 96 locations shown in the figure, do not drill a hole all the way through or there
could be a problem when installing the new part.



ac5wzb00000142

2. Remove the trunk floor panel.