
FRONT UNDER COVER No.2 REMOVAL/INSTALLATION

id091600888900

- 1. Lift up the vehicle.
- 2. Remove the front under cover No.1. (See FRONT UNDER COVER No.1 REMOVAL/INSTALLATION.)
- Remove fasteners A.



ac5wzw00003030

- 4. Remove bolts B.
- 5. Remove the front under cover No.2.
- 6. Install in the reverse order of removal.