## **OIL STRAINER [GW6A-EL, GW6AX-EL]**


id0517i2355300

## **Purpose/Function**

• The oil strainer filters particulate matter in the ATF by passing it through the built-in filter.

## Construction

• The oil strainer is a built-in, non-woven fabric filter installed to the position shown in the following figure.



am3uun00002256