## **CRANKSHAFT PULLEY [SKYACTIV-D 2.2]**


id0110s5001000

## **Purpose, Function**

- The crankshaft pulley transmits the drive force to the auxiliary parts via the drive belt.
  The crankshaft pulley suppresses torsional vibration of the crankshaft.

## Construction

- The crankshaft pulley is installed to the front of the crankshaft.
- The crankshaft pulley has key groove to match the timing to the crankshaft.
  The crankshaft pulley has a torsional damper for suppressing torsional vibration of the crankshaft.



ac5wzn00000124